

657154 Sizzix® Bigz™ Pro Die - Box, Popcorn #2



1. Die-cut two Popcorn Box sides and one bottom piece from chosen material. Fold and apply adhesive as shown.



2. Connect the two sides.



3. Adhere the remaining flap to the opposite side to complete the body of the Box.



4. Close the bottom of the Box by folding in the plain flaps first.



5. Slide the pointed ends of the two remaining flaps underneath each other to lock the bottom closed.



6. Insert the bottom square. This serves two purposes. It adds strength to the bottom of the Box, and it keeps the Box square so that the flaps do not slide apart. While not necessary, you may use an adhesive to attach the bottom square.

657154 Sizzix® Bigz™ Pro Die - Box, Popcorn #2



7. Embellish as desired.